

NEWKEY/80 Quick Reference

Ctrl

Alt

Commands

- A** About
- H** Help
- delete** Reset TRS-80
- break** Reset TRS-80 and bypass floppy
- space** Reset TRS-80 and bypass FreHD
- R** Reset NEWKEY/80
- 1**, **3**, or **4** Change TRS-80 Model


Basic Programs

- I** TRS-IO Retrostore Client Loader
- P** NEWPRINT Test Program

Output Key Delay

- ↑** Increase keyboard delay
- ↓** Decrease keyboard delay

Win

Hold the  key to enable multiple key entry

Note: Most modern USB keyboards do not handle TY/GH/BN combinations very well (or not at all).

Alt

Multi-key Shortcuts (used by some versions of DOS)

- 1** 123 (Debug)
- D** DFG (MiniDos)
- J** JKL (Screen Print)